

## **ESI Communications Servers**

## Call Forward Set & Cancel

- 1. Press CFWD or other programmed FORWARD key to use the Call Forward feature
- 2. Dial the extension number OR external phone number to which calls should forward
- 3. Press # key to confirm
- 4. To cancel Call Forward, press the CFWD or other programmed FORWARD key, then press \*.

## **Call Transfer**

- 1. Transfer to another extension: while connected to a call, press a station key (or press TRANSFER and dial the extension number). Hang up to complete the transfer.
- 2. Transfer to a mailbox: while connected to a call, press VOICE MAIL, then the extension button or extension number. Hang up to complete the transfer.

## **Conference Calls**

- 1. While on a call, press CONF
- 2. Add the next party to the conference:
  - a. To add an internal extension to the call, dial the extension number
  - b. To add an external number to the call, press a line key or line access code (8 or 9), then dial the outside phone number normally.
- 3. When the party answers, press CONF to join all parties together
- 4. To add more participants, repeat steps 1-3 as needed